




Vintage Keeper®

500



ASSEMBLY & OPERATION MANUAL

READ BEFORE YOU START

LOCATING YOUR WINE CELLAR

Provide 2 1/2" minimum clearance for both sides and back; keep the top clear.

Never locate your wine cellar outdoors or in an area with extremes of temperature and humidity. These units must be placed/located/operated in air-conditioned environments which do not "trap" the warm air exhaust.

Temperatures in surrounding area must not exceed 80 °F (25 °C) with relative humidity levels not to exceed 70% R.H.. Never set your temperatures below default (57°F) whenever ambient conditions are warm (above 75°F) or humid (above 50%R.H.).

Outlet power must be a DEDICATED separately fused, grounded, 15 Amp 110 - 120 V line or 7.5 Amp - for 240 V models (CHECK BOX OR SERIAL NUMBER LABEL ON UNIT FOR YOUR LINE VOLTAGE REQUIREMENTS).

You must monitor your unit DAILY. If unit is in "Alarm", unplug the unit immediately.

Koolr Products Inc. will not be liable or responsible for incidental or consequential damages. (See Warranty).

Place unit in a clean area and allow access to the exterior surfaces for periodic vacuuming of the condenser coil. (See troubleshooting for details.)

Clean using a damp cloth and no detergents or polishes under any circumstances.

Always remove all bottles before relocating your wine cellar.

AREA FOR ASSEMBLING YOUR WINE CELLAR

Choose a clear 12' by 8' area with a level floor. Place soft material underneath (carpet) to avoid scratching!

TOOLS

Rubber mallet, hex wrench (included), phillips screwdriver.

Helper is needed.

TEST THE COOLING UNIT

Plug it in on a table top, to verify that controls and display are functional, and that the unit is producing cool air after a few minutes of operation.

Note that the electronic controller has a one-minute safety delay between initial plug-in and start-up of the compressor.


BEFORE YOU START !

Fill out the WARRANTY REGISTRATION FORM. You will find the serial number for the form located on the LEFT SIDE of the unit or on the light cord.


HARDWARE

(OPEN ALL BOXES AND PACKAGES FIRST!)


HINGES









DISCARD !



CONNECTOR PLATES




- A**  Hinge Washer x 2
- B**  Legs x 6
- C**  Cooling Unit Bolt in cooling unit box x 2
- D**  Allen Key in cooling unit box x 1
- E**  Hook x 2




1

PLACE BACK AGAINST WALL
REMOVE RIGHT CORNER
INSERT POST 1 INTO BACK



2

REINSERT RIGHT CORNER INTO BACK RIGHT
PLACE BACK AGAINST WALL
INSERT BACK RIGHT INTO POST 1



3


INSTALL SIDES

GET HELPER TO GUIDE IN SIDES

USING RUBBER Mallet TAP LEFT AND RIGHT SIDES INTO PLACE



DO NOT LIFT SIDE WHEN SLIDING IN



PLACE SPACERS ON BACKS
OVER HANG SPACERS FROM EDGE

4

INSTALL BOTTOM


(HELPER NEEDED)

1. STRETCH SIDES TO INSERT BOTTOM



2. REST BOTTOM ON SPACERS

OUTSIDE


3. PRESS IN SIDES FULLY



4. PULL OUT SPACERS



5. KEEP SIDES PRESSED
PUSH DOWN BOTTOM FULLY




5

INSTALL BOTTOM CONNECTOR PLATES

HAND PRESS IN ALL CONNECTOR PLATES IN BOTTOM


TAP IN CONNECTORS TIGHTLY (NO GAP) WITH CLOSED HAND OR RUBBER Mallet

SCREW IN ALL LEGS **B ⚠️ LEAVE 1/4" SPACING ON ALL LEGS**




INSTALL TOP AND CONNECTOR PLATES

REPEAT STEP 4 ON PAGE 7 FOR TOP



⚠ DO NOT INSTALL HINGES YET! ⚠



INSTALL TOP CONNECTOR PLATES



7

INSTALL CENTER POSTS

ALIGN TO SLOTS AND TAP TO LOCK




INSTALL DOORS AND HINGES

PLACE WASHERS FIRST
PLACE DOORS ON CABINET
SLIDE DOORS ON TO BOTTOM HINGE

INSTALL TOP HINGES

TURN BOTH CENTER LEGS
1 TURN COUNTER CLOCKWISE
TO RAISE LEGS SLIGHTLY



! STAND THE UNIT UP NOW!
HELPER NEEDED

NOTE: DOOR GASKET WILL RELAX IN A FEW DAYS ASSURING A GOOD SEAL


9

INSTALL BRACES 5 AND 6



(HELPER NEEDED TO HOLD CABINET STEADY)



ALIGN TO TABS, PUSH DOWN BRACES 5 (X 2)
AND 6 (X 2)



10

INSTALL SHELVES


 (HELPER NEEDED TO HOLD CABINET STEADY)





PLACE COOLING UNIT IN CABINET

 (HELPER NEEDED TO HOLD CABINET STEADY)


KEEP UNIT LEVEL



DO NOT!!!



**CORD MUST
CLEAR OPENING**




**STRAIGHTEN AND
PUSH THROUGH**

GET HELPER TO
PULL FROM INSIDE
AND LIFT UNIT
LEVEL DURING
FASTENING

**BOLTS (C)
IN COOLING
UNIT BOX.**

**KEEP UNIT LIFTED
UP INSIDE
DURING FASTENING!**




TIGHT!

12


CONNECT LIGHT AND HOOKS

LED LIGHT : WARM WHITE GLOW FOR NATURAL LIGHTING, NO HEAT, ENERGY EFFICIENT




INSTALL HANDLE


13



PLACE LOGO





LEVEL CELLAR REMOVE VISIBLE STICKERS



COMPENSATE FOR YOUR FLOOR

LEVEL DOOR

TIP: ADJUST LEGS TO HELP LEVEL DOOR
ADJUST HINGES IF REQUIRED



**NEVER MOVE LOADED CABINET !
EMPTY FIRST !**


DISASSEMBLY

REMOVE COOLING UNIT AND SHELVES






LAY CELLAR DOWN

FULLY TIGHTEN LEGS

PRY OFF ALL CONNECTOR PLATES WITH FLAT SCREWDRIVER



REUSE LEG
FOR TOP HINGES
AND CENTER REAR



TIGHTEN LEGS
FULLY

PRY OFF
CONNECTOR PLATE

CONTROLS : PLUG IT IN (wait one minute) and ENJOY!

FEATURES:

Default SET temperature 57° F/14° C (ideal for wine storage).
 Calibration option of the temperature sensor.
 Display of actual temperature by request.
 SET temperature range 52°F-64°F.
 Digital temperature sensor.
 Dual display F°/C°.
 Settings are stored in memory for power failures.
 Pre-programmed software will establish the quietest most efficient operation.

DISPLAY:



KEYS

OPERATION:

The display will show the detected temperature until the temperature falls within $\pm 3^\circ$ of the SET POINT (normal cooling range).
 If the temperature is above the default 57° F + 1° or other preset value, after a **delay of 1 minute** the fan will start, followed by the compressor within the next minute.
 The unit will cycle ON/OFF based on the temperature reading. Fan speeds are automatically set by the controller to achieve optimum performance.
 Minimum ON and OFF cycle times are imposed by software, to prevent "short cycling".

CONTROLLER OPERATION	ACTION	DISPLAY EXAMPLE	
			BEFORE
TO DISPLAY:	Actual temperature: PRESS	57°	56°
	SET temperature: PRESS	70°	57°
TO MODIFY SET TEMPERATURE (range is 52-64°F):	PRESS and RELEASE	57°	57°
	To increase: PRESS once per degree	57°	58°
	To decrease: PRESS once per degree	57°	56°
	The new value will be memorized and the controller will reset automatically.		
TO CHANGE FROM °F to °C: or °C to °F	PRESS and HOLD until buzzer sounds in 5 seconds	57°	14°
	The new value will be memorized and the controller will reset automatically.		
TO CALIBRATE:	PRESS and HOLD while holding PRESS and RELEASE BOTH QUICKLY	57°	57°
	Wait 5 seconds	57°	F0
	USE for each degree of positive offset	F0	F1
	for each degree of negative offset	F0	-1
NOTE: A negative offset will result in a warmer cabinet and a positive offset will result in a cooler cabinet. The new value will be memorized and the controller will reset automatically.			

SAFETY FEATURES:

ALARM:

- If the temperature exceeds 72° F the unit will shut down, a sound warning will start and the display will blink alternating with the temperature reading.
- This function is disabled in the first 4 hours "Cool Down" period or after any reset for another 4 hours.
- The unit will restart and continue the cooling and cycling if the temperature falls below 72° F.


AL

TO RESET: - Unplug and re plug the unit after 10 minutes.

MAXIMUM CAPACITIES AND LOADING TIPS

Maximum capacities and sample loading arrangements for Winekoolr wine cellars are illustrated below. Standard Burgundy and Bordeaux bottles are best arranged with necks facing out; some taller bottles may need to be arranged neck to neck. Never stack bottles more than two rows high on a shelf; all shelves must be installed as directed. Avoid placing bottles directly in front of the cooling unit's circulating fan for more uniform temperature in cabinet.

MODEL 500



Maximum capacity 500 bottles
Based on 10% (50 x 1/2 bottles)

IMPORTANT NOTE

The top shelf of the cabinet should have the coldest temperature and may be used as your "chilling" section.

All Wine Cabinets have minor differences in temperature depending on where articles are stored. Top to Bottom differences will be present in any Cellar due to layering and pressure differences. The coldest temperatures will occur closest to the "Top" where the cold air originates.

The temperature readout represents samples of the air close to the position of the sensor. Other points in the cabinet will vary according to many factors, including the type of bottle loading, proximity to the door, corners, exposure to outside temperature, door usage etc. Just as in air conditioned rooms and refrigerators, not all locations measure the same temperature.

For example if you measure the air temperature exiting the coil, it will always be substantially colder than the set temperature. It is this basis that governs the ultimate temperature of any specific point in any cabinet.


Please make sure not to block the air flow under, and to the right side of the cooling unit. This would direct the cold air back into the cooling unit causing short cycles.

Remember, the important element for storing wine is constant temperature, not absolute temperature. We do guarantee that if your cellar is working normally the liquid temperature of your wine will not fluctuate even 1/4 of a degree C.

TROUBLESHOOTING GUIDE

Although each Vintage Keeper cooling unit has been carefully tested at every stage of manufacture, occasional problems arise, the majority of which are due to rough or careless handling during shipping or installation. Other issues may occur due to improper cabinet assembly, power interruption or surge, low line voltage (less than your unit rating of 105V or 240V), or failure to clean the unit regularly (see illustration below). The following may help you determine what the problem may be; what steps you can take to correct it, and what further steps may be required. Additional Trouble-Shooting information and downloadable documents are available in the “Support” area of our website: www.koolrproducts.com

CLEANING THE COIL:



IMPORTANT NOTE:

In order to provide maximum protection for your valuable wine collection, the following steps are highly advisable. First and foremost, have your wine collection adequately insured. Second, install a battery-powered heat-sensitive alarm to warn of any loss of cooling due to power interruption. Third, monitor your storage and ambient conditions on a regular, daily basis. Fourth, install a high quality surge suppressor to protect against sudden power fluctuations. Fifth, clean the unit as directed, on a regular basis. Every 3 to 4 months vacuum the cooling unit coils (check our website for more info). Be advised, also, that Koolr Products Inc. or Shanghai Koolspace Co. Ltd. cannot in any event be liable or responsible for incidental or consequential damages.

IF:	CHECK:	THEN:
COOLING UNIT DOES NOT RUN AT ALL WHEN PLUGGED IN	<ul style="list-style-type: none"> Is the unit plugged in? Is the power supply operational? Is the LED display functional? Is there any evidence of shipping damage on the cooling unit or packaging materials? 	<ul style="list-style-type: none"> Note that the unit has a 1-minute cautionary delay between plugging in and full start-up; this is a built-in safeguard to protect the compressor in the event of sudden power failure Note that the power supply must be a dedicated, separately-fused and grounded 15 Amp, 120V line or 7.5 Amp, 240 V line rated for your unit. Must not use an extension cord. Do not share the outlet with other appliances If the unit is receiving power yet fans or compressor fail to run, unplug for ten minutes, then try again. <p>for more help please go to : www.koolrproducts.com/support.html (Troubleshooting)</p>
COOLING UNIT RUNS BUT DOES NOT COOL SUFFICIENTLY	<ul style="list-style-type: none"> Is the storage temp properly set? Is the cabinet properly assembled? Is airflow to and from the cooling unit unobstructed? Is the ambient air temperature within the specified range? Are any exterior surfaces of the cabinet exposed to sunlight? 	<ul style="list-style-type: none"> Note that the unit may take a few days to achieve the desired storage temperature, even in a properly located, airtight cabinet Take steps to reduce ambient temperatures and compensate for additional heat gain if any cabinet walls receive direct sunlight Take steps to improve circulation of air to and from the unit Adjust the legs to level the door for proper magnetic gasket seal Increase your SET TEMPERATURE Clean the grill areas <p>If the problem persists, go to our website at www.koolrproducts.com/support.html (Troubleshooting) and perform the “cooling unit diagnostic” in the support section.</p>

LIMITED WARRANTY AND PRODUCT SUPPORT

ONE YEAR LIMITED WARRANTY

If your Vintage Keeper cooling unit or cabinet fails to perform as designed within one year of the date of purchase, Shanghai Koolspace Co. Ltd. warrants that, upon your request, it will be repaired or replaced, at our option, during the one year warranty period. This warranty applies only to the first end-user purchaser of a Vintage Keeper cooling unit that is purchased and used in the continental United States or Canada (excludes Alaska and Hawaii). It is not valid for subsequent purchasers, nor for units in use outside North America. The warranty period for your Winekoolr cooling unit commences on the date you purchased it and expires one year thereafter.

PROOF OF PURCHASE

Within 10 days of purchase, complete and mail, fax or e-mail the registration sheet to Shanghai Koolspace Co. Ltd. Alternately, you may register your warranty on our Internet website, www.koolrproducts.com. When you make a warranty claim, you must forward a copy of your original dated bill of sale to establish your date of purchase.

IF YOU HAVE A PROBLEM WITH YOUR UNIT

Customer service and warranty problems are handled online at www.koolrproducts.com. You will find a comprehensive well-documented and easy-to-use solution to almost any question or problem you may have. The inquiry forms are filled in on-line and connect you to our representatives who will process your requests for warranty service. This is the quickest way to solve your problems.

REPLACEMENT ?

At our option we may choose to offer you a replacement part or product rather than a repair. Upon your authorization to accept a replacement unit and with appropriate security (credit card authorization), we will promptly ship a replacement unit. The replacement may be a unit that has been reconditioned by Shanghai Koolspace Co. Ltd. The unit that needs service must be packed and returned to us, shipping prepaid. Upon its receipt, we will release your credit card security. Go online to the SUPPORT section on our website at www.koolrproducts.com to request warranty service.

WHAT MUST YOU DO?

Your unit is designed to perform with a minimum amount of user maintenance when **installed and operated precisely as directed in the manual**. You are, however, responsible for the required user maintenance described in the manual, specifically, regular cleaning of the condensor coil. Also, you must take steps to protect the unit from sudden power surges. As with any sensitive electronic device, your Winekoolr cooling unit may be damaged by power surges or spikes, including lightning strikes, acts of God, sudden interruptions or prolonged low-voltage conditions, which are not covered by this Warranty. You must monitor your unit's performance on a daily basis. If there is an apparent problem or "Alarm" condition, you must disconnect the power supply to avoid potential damage to your wine collection. It is your responsibility to insure your wine, and to take all reasonable and necessary precautions to safeguard its condition.

WHAT THE WARRANTY DOES NOT COVER

This warranty covers only defects in materials and workmanship provided by Shanghai Koolspace Co. Ltd. and does not cover equipment damage or malfunction from misuse, abuse, accident, acts of God, or any unauthorized alteration or modification. The product must have been installed and operated precisely as directed in the manual which accompanies each product. Improper return shipping, inadequate packaging or shipping damage is not covered unless the unit is packaged and shipped in accordance with Shanghai Koolspace Co. Ltd. replacement procedures. Third party servicing of this product during the warranty period will also void the warranty, as will any evidence of tampering or alteration to the serial number and or the original dated bill of sale.

REPLACEMENT AND REPAIR ARE YOUR ONLY REMEDIES

YOUR ONLY REMEDY UNDER THIS WARRANTY IS THE REPLACEMENT OR REPAIR OF YOUR ELIGIBLE PRODUCT AS DESCRIBED ABOVE. NEITHER THIS WARRANTY NOR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL EXTEND BEYOND THE ONE-YEAR WARRANTY PERIOD. UNDER NO CIRCUMSTANCES SHALL SHANGHAI KOOLSPACE CO. LTD. BE LIABLE FOR ANY SPECIAL INCIDENTAL, INDIRECT OR PUNITIVE DAMAGES OR FOR ANY CONSEQUENTIAL DAMAGES, INCLUDING SPOILAGE OF WINE, EVEN IF SHANGHAI KOOLSPACE CO. LTD. KNOWS OR IS INFORMED THAT SUCH DAMAGES ARE POSSIBLE. IT IS YOUR RESPONSIBILITY TO INSURE YOUR WINE, AND TAKE ALL REASONABLE, NECESSARY PRECAUTIONS TO SAFEGUARD ITS CONDITION. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU. NO RESELLER IS AUTHORIZED TO MODIFY THE TERMS OF THIS WARRANTY. ANY ADDITIONAL WARRANTY OFFERED BY A RESELLER IS THE SOLE RESPONSIBILITY OF THAT RESELLER.

SERVICE AFTER YOUR WARRANTY EXPIRES

If your unit requires service after the one-year warranty period expires, you may have it serviced locally by a qualified HVAC technician, or you may purchase a **new** unit at a **special discount** under our Extended Warranty Program. Please be ready to provide model, serial number, and your credit card. Let us assure you that local servicing will always be a **more** expensive and less satisfactory solution. More often than not repairs are not properly done and almost always take longer and cost more than purchasing a discounted **new** unit. Go online at www.koolrproducts.com to request Replacement or see our Extended Warranty Program.